

CAPS

INTERNATIONAL

JACKET HOLD DOWN

The jacket hold down is shipped with the handle unassembled. Check the carton carefully to insure the handle is not accidentally discarded. The screws for the handle are shipped in the frame. Remove the screws from the frame, start all of the screws with the handle in place on the frame. Do not tighten the screws until all of the screws are in place. Do not over-tighten.

Always leave the hold down unit in the open position when not in use or when in storage.

The handle locks down in one easy motion that pulls the jacket fabric tight for one color or multi-color printing. Self adjusting rubber blades provide the correct pressure for thick quilted jackets or thin nylon jackets.

The spring loaded lifter holds the clamp open while loading the jacket. It adjusts to accommodate light to heavy weight jackets. No adhesive is required.

P O Box 48188, Sarasota, FL 34230
(423) 283-4788 (800) 330-5515 (423) 283-4545 Fax
www.caps-screenprinting.com E-Mail: caps@naxs.net