

CAPS

INTERNATIONAL

HALOGEN BENCH MODEL EXPOSURE UNIT OPERATIONAL STEPS

- | <u>STEP</u> | <u>PROCEDURE</u> |
|--------------------|---|
| 1. | Place art work on screen front. |
| 2. | Place glass cover over art work. |
| 3. | Set halogen light 12 to 15 inches above glass surface. |
| 4. | Expose image for approximately seven (7) minutes. |
| 5. | Remove glass cover and artwork. |
| 6. | Washout screen image. |
| 7. | Dry screen thoroughly. |
| 8. | Print job. |